

DIMM

INSTALLATION GUIDE

Preparation

For safe operation, see "Safety Information", *Maintenance Guide*.

CAUTION:

- Do not touch the inside of the controller board compartment. It may cause a machine malfunction or a burn.

Important


- ❑ Before touching the DIMM, touch something metal to discharge any static electricity. Static electricity can damage the DIMM.

Installing the DIMM

- 1** Turn off the power.
- 2** Unplug the power cord, and then disconnect the interface cable.
- 3** Remove the two screws that are fastening the controller board on the back of the printer using provided screwdriver. 


Reference

See "How to Use the Screwdriver", *Setup Guide*.




The removed screws will be used in step **8** to fasten the controller board.

- 4** Holding the handle, pull out the controller board slowly.




- 5** Put the controller board on a flat surface.

- 6** Insert the DIMM into the slot, and push it down until it clicks. If the DIMM is not set in the correct way, it does not click.




- 7** Adjust the controller board to the top and bottom rails, and then push in slowly until it stops.



Important

- ❑ The printer may not work properly if the controller board is not set properly.

- 8** Tighten the two screws that you removed in step **3** to fasten the controller board back into its original position using provided screwdriver.



Note

- ❑ Be sure to return the provided screwdriver to its original position on the inside of the front cover.

- 9** Attach the interface cable, and then plug in the power cord.

- 10** Turn on the power.

Note

- ❑ After finishing installation, print the configuration page from the "List/Test Print Menu" to confirm that the DIMM is installed properly. See "List/Test Print Menu", *Administrator Reference*, on the CD-ROM labeled "Operating Instructions".