



# OCR + Barcode-Schriften sos8026G

Auf dem mitgelieferten USB-Stick sind alle notwendigen Daten bereits enthalten. Die Schriften ist somit sofort nach dem Einsetzen in das zuvor ausgeschaltete Endgerät verfügbar („plug-and-print“).

Eine Prüfung ob der USB-Stick korrekt erkannt wurde kann ausschließlich durch drucken der PCL Schriftenliste nachvollzogen werden:

Druck über das Bedienfeld vom Endgerät:	Druck über EWS:

Bei der korrekten Funktionsweise erscheinen unter der Überschrift USB1 die anzusteuern Schriften auf mehreren der gedruckten Seiten (Auszug siehe rechts).

Alle Angaben ohne Gewähr, Stand Februar 2023

**PCL Font List** HP Color LaserJet FlowMFP M577  
Page 02

USB1	Font Name	Encoding	Font Size
	Scalable	cmrj	0001
	Scalable	cmrj	0002
	Scalable	cmrj	0003
	Scalable	cmrj	0004
	Scalable	cmrj	0005
	Scalable	cmrj	0006
	Scalable	cmrj	0007
	Scalable	cmrj	0008
	Scalable	cmrj	0009
	Scalable	cmrj	0010
	Scalable	cmrj	0011

# OCR + Barcode-Schriften sos8026

Die Programmieranleitung befindet sich auf folgender Webseite:

<http://sos8026.stethos.com>

[Deutsche technische Programmieranleitung](#)


Fast alle HP Ausgabegeräte besitzen intern ab Werk keine USB Steckplätze mehr. Diese müssen für den Betrieb eines USB Barcode-Sticks aus dem Hause stethos mit einem zu dem Ausgabegerät passenden HP Zusatzprodukt nachgerüstet werden.

Neuere HP Geräte (Einführung Mitte 2022 und später) benötigen den ab April 2023 ausgelieferten 2-in-1 USB Stick mit USB-A (weiblich) und USB-C (männlich) Anschluss zum Betrieb eines Barcode-Sticks mit dem HP Zubehör 4XN67A. Eine Endgeräte-Kompatibilitätsliste bzgl. der Erweiterungskits finden Sie auf der Webseite: <http://hpusb.stethos.com> (ohne Gewähr)

Abbildung HP B5L28A (USB-A)



Abbildung HP 4XN67A (USB-C)



Anleitung <http://B5L28A.stethos.com>

Anleitung <http://4XN67A.stethos.com>

Hinweis: stethos liefert keine HP Artikel. Falls HP bzw. der HP-Lieferant die USB-Erweiterung nicht kurzfristig liefern kann so besteht die Möglichkeit, den stethos USB-Barcode-Stick auch am hinteren externen USB-Anschluss vom HP-Endgerät zu betreiben. Bei diesen Geräten muss das in jedem Fall erfolgen: E40040dn, MFP E42540f, Color E45028dn, Color MFP E47528f, M406dn, M407dn, MFP M430f, MFP 431f, Color M455dn und MFP M480f.





# OCR + Barcode Fonts sos8026G

The supplied USB-Stick does contain all needed data. The fonts are immediately available once the stick is inserted in the switched off HP device (“plug-and-print”).

The only chance to check if the USB-Stick works well you must print a PCL Font List:

**Invoke the print from the device front panel:**

**Print from the EWS:**

**PCL Font List** HP Color LaserJet FlowMFP M577  
Page 02

**USB1**

Font	Pitch/Point	Envelope	Color	Font #	Font ID
	Scalable	400x100	Yellow	3231	0001
	Scalable	400x100	Yellow	3231	0002
	Scalable	400x100	Yellow	3231	0003
	Scalable	400x100	Yellow	3231	0004
	Scalable	400x100	Yellow	3231	0005
	Scalable	400x100	Yellow	3231	0006
	Scalable	400x100	Yellow	3231	0007
	Scalable	400x100	Yellow	3231	0008
	Scalable	400x100	Yellow	3231	0009
	Scalable	400x100	Yellow	3231	0010
	Scalable	400x100	Yellow	3231	0011

If some pages with additional fonts are listed below the headline USB1 then everything works well (parts are shown on the left).

No liability and subject to change without notice, dated February 2023



# OCR + Barcode Fonts sos8026

The programming manual can be found here:

<http://sos8026.stethos.com>

[English technical programming manual](#)

Almost all of the HP output devices do not have internal USB ports when delivered out of the box. When using a USB barcode module from stethos you will have to add a suitable HP accessory part number which fits into the device.


Newer HP devices (introduction date mid 2022 and later) do need the 2-in-1 USB Stick with a USB-A (female) and a USB-C (male) connector in order to operate the Barcode stick with the HP accessory 4XN67A. A device compatibility list is available on the website:

<http://hpusb.stethos.com> (no liability)

Picture HP B5L28A (USB-A)



Picture HP 4XN67A (USB-C)



Manual <http://B5L28A.stethos.com>

Manual <http://4XN67A.stethos.com>

Note: stethos is unable to deliver any HP parts. Once HP or your HP reseller cannot deliver this part in a reasonable timeframe, you can also attach the stethos USB barcode module to the external USB port on the rear of your HP device (pictured on the right). For these HP devices only external attachment is possible: E40040dn, MFP E42540f, Color E45028dn, Color MFP E47528f, M406dn, M407dn, MFP M430f, MFP 431f, Color M455dn und MFP M480f.

