

# DIMM

## INSTALLATION GUIDE

### Preparation

For safe operation, see "Safety Information", *Maintenance Guide*.

### CAUTION:


- Do not touch the inside of the controller board compartment. It may cause a machine malfunction or a burn.

### Important

- ❑ Before touching the DIMM, touch something metal to discharge any static electricity. Static electricity can damage the DIMM.

## Installing the DIMM


- 1** Turn off the power.
- 2** Unplug the power cord, and then disconnect the interface cable.
- 3** Remove the two screws that are fastening the controller board on the back of the printer.



ZHBP080E

The removed screws will be used in step **3** to fasten the controller board.


- 4** Holding the handles, pull out the controller board slowly.



ZHBP020E


- 5** Put the controller board on a flat surface.

- 6** Insert the DIMM into the slot, and push it down until it clicks. If the DIMM is not set in the correct way, it does not click.



ZHBPP120E

- 7 Adjust the controller board to the top and bottom rails, and then push in slowly until it stops.




ZHBP070E

### Important

- The printer may not work properly if the controller board is not set properly.

- 8 Tighten the two screws that you removed in step 3 to fasten the controller board back into its original position.



ZHBP010E

Use a coin to fasten it securely.

- 9 Attach the interface cable, and then plug in the power cord.
- 10 Turn on the power.

### Note

- After finishing installation, print the configuration page from the "List/Test Print Menu" to confirm that the DIMM is installed properly. See "List/Test Print Menu", *Administrator Reference*, on the CD-ROM labeled "Operating Instructions".